

BYD BATTERY-BOX PREMIUM HVS&HVM COMPATIBLE INVERTER LIST – V1.6



Inverter		HVS 5.1	HVS 7.7	HVS 10.2	HVS 12.8	HVM 8.3	HVM 11.0	HVM 13.8	HVM 16.6	HVM 19.3	HVM 22.1	
Fronius*	Symo Hybrid*	-	-	-	-	✓	✓	✓	✓	✓	✓	
	Primo Gen24 Plus*	✓	✓	-	-	-	✓	✓	✓	✓	-	
	Symo Gen24 Plus*	✓	✓	✓	-	-	✓	✓	✓	✓	✓	
	*Planned configuration – not officially released yet. Could be subject to change											
GoodWe	ET	✓	✓	✓	✓	-	✓	✓	✓	✓	✓	
	BT	✓	✓	✓	✓	-	✓	✓	✓	✓	✓	
	EH	✓	✓	✓	-	✓	✓	✓	✓	✓	✓	
	BH	✓	✓	✓	-	✓	✓	✓	✓	✓	✓	
	HVM Released (CW15); HVS Released (CW29) Firmware: GoodWe Inverters (ARM) ≥ V11 BYD Battery-Box Premium HVM & HVS: BMU ≥ V3.7, BMS ≥ V3.16;											
KOSTAL	Plenticore Plus 3.0	✓	✓	✓	✓	-	✓	-	-	-	-	
	Plenticore Plus 4.2/5.5/7.0/8.5/10.0	✓	✓	✓	✓	-	✓	✓	✓	✓	✓	
	Plenticore BI 5.5-13, 5.5-26	✓	✓	✓	✓	-	-	✓	✓	✓	✓	
	Plenticore BI 10.0-26	-	✓	✓	✓	-	-	✓	✓	✓	✓	
	Released (CW17) Firmware: KOSTAL Inverters ≥ 01.42. BYD Battery-Box Premium HVS & HVM: BMU ≥ 3.7, BMS ≥ 3.16											
	Piko MP Plus 1.5-1, 2.0-1, 2.5-1	✓	✓	-	-	✓	✓	-	-	-	-	-
	Piko MP Plus 3.0-1, 3.0-2, 3.5-1, 3.5-2, 4.6-2, 5.0-2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Released (CW26) Firmware: KOSTAL Inverters ≥ PU-APP 3.7.0, KSEM ≥ 1.2.0. BYD Battery-Box Premium HVS & HVM: BMU ≥ 3.7, BMS ≥ 3.16											



Inverter		HVS 5.1	HVS 7.7	HVS 10.2	HVS 12.8	HVM 8.3	HVM 11.0	HVM 13.8	HVM 16.6	HVM 19.3	HVM 22.1
SMA*	Sunny Boy Storage 2.5*	✓	✓	✓	–	–	–	–	–	–	–
	Sunny Boy Storage 3.7*	✓	✓	✓	–	✓	✓	✓	✓	✓	✓
	Sunny Boy Storage 5.0*	–	✓	✓	–	–	✓	✓	✓	✓	✓
	Sunny Boy Storage 6.0*	–	✓	✓	–	–	–	✓	✓	✓	✓
	*HVS planned configuration – not officially released yet. Could be subject to change					Released (CW29) Firmware: SMA Inverters ≥ 3.11.03.R; BYD Battery-Box Premium HVS & HVM: BMU ≥ 3.12, BMS ≥ 3.18					
Sungrow	SH5.0/6.0/8.0/10RT	✓	✓	✓	✓	–	✓	✓	✓	✓	✓
	Released (CW20) Firmware: Sungrow Inverters ARM ≥ V11_V01_A, MDSP ≥ V11_V01_A. BYD Battery-Box Premium HVS & HVM: BMU ≥ 3.7, BMS ≥ 3.16										
KACO*	Blueplanet hybrid 6.0 - 10.0 TL3*	✓	✓	✓	–	✓	✓	✓	✓	✓	✓
	*Planned configuration – not officially released yet. Could be subject to change										

NOTICE

1. Maximum three battery systems could be connected in parallel. The below requirements must be fulfilled under parallel connection:

- HVS system CANNOT be connected in parallel with HVM system;
- Every system connected in parallel requires the same module quantity.
- Parallel connection is not applicable to SMA Sunny Boy Storage 3.7-6.0. Please check the inverter operation manual on how to connect up to three batteries.

2. Installation before official release is not allowed.

3. Configurations marked in grey are not released yet and are not allowed to be installed yet. Those configurations are planned and will follow soon. The actual configuration upon official release might change.



BYD Company Limited
www.bydbatterybox.com
Global Sales: batteryboxgrp@byd.com
Global Service: bboxeservice@byd.com

Battery-Box EU Service Partner
EFT-Systems GmbH
www.eft-systems.de
info@eft-systems.de

Battery-Box AU Service Partner
Alps Power Pty Ltd
www.alpspower.com.au
service@alpspower.com.au

Version V1.6; Update: 2020-07-17

